



Inputs 0-7 (Oriented as above)

| | | | | | | | | | |
|----|-----|----|-----|----|-----|----|---|----|----|
| 7 | 6 | 5 | N/C | 4 | N/C | 3 | 2 | 1 | 0 |
| 0v | N/C | 0v | 0v | 0v | 0v | 0v | | 0v | 0v |

Inputs 8-15 (Oriented as above)

| | | | | | | | | | |
|----|-----|----|----|----|-----|----|-----|----|----|
| 15 | 14 | 13 | | 12 | N/C | 11 | 10 | 9 | 8 |
| 0v | N/C | 0v | 0v | 0v | 0v | 0v | N/C | 0v | 0v |

Outputs 0-7 (Oriented as above)

| | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|---|-----|
| 12v | 12v | N/C | 12v | 12v | 12v | 12v | 12v | | 12v |
| 0 | 1 | 2 | 3 | N/C | 4 | N/C | 5 | 6 | 7 |

Outputs 8-15 (Oriented as above)

| | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 12v | 12v | N/C | 12v | 12v | 12v | 12v | 12v | N/C | 12v |
| 8 | 9 | 10 | 11 | | 12 | N/C | 13 | 14 | 15 |

LED Usage:

| | |
|----------------|-----------------------------------|
| RED on | USB not connected (electrical) |
| RED flashing | No contact with PC driver program |
| RED off | PC driver is active |
| Green Off | USB not working |
| Green flashing | Application not running |
| Green On | Application running |